



## **Mounting manual canopy, CITROËN TA, as of 1952**

1. Tack or rivet weather strips.
2. Fix the bearded metal strips to the body.
3. Mount the wooden rear window frame together with the metal window frame.
4. Find the middle of the canopy and let it coincide with the middle of the car.
5. When hanging the canopy, start at the back of the car. At the place where the hanging hooks are fixed to the whalebone an opening of approx. 5 cm has to be cut out of the hanging cloth in order to enable stretching to the sides.
6. Stretch the canopy to the side and fix to the barbs. Start at the back and work to front. Leave the end of the cloth in sign to be able to push it up when everything is finished.
7. Glue the canopy under the rear window to the carbon board strip and fix it to the parcel shelf.
8. Finally cut out the rear window (do not make the hole too big) and fix the canopy to the wooden frame .

**Good luck,**

**Classic Automobile Service  
WWW.CAS-SHOP.COM**